
HBI600/609

Wire Guard Installation Instructions


Wire Guard Number Luminaire Length

WG11-HBI600 HBI600 WG11-HBI609 HBI609



STEP 1

Install self-retaining nuts in slots along sides of luminaire housing. Flat surface of nut must face outside, and holes in nuts must align with holes in housing.





STEP 2

Place the wire guard on the housing and the wire guard clips over it.





STEP 3

From the outside of the housing, insert the thumb screw through the wire guard clip and the self-retaining nut. Gradually tighten the thumb screw to lock the wire guard in place against the housing.





Los Angeles Lighting Mfg. Co. assumes no responsibility for claims arising out of improper or careless handling or installation of this product.



Los Angeles Lighting Mfg. Co.

10141 OLNEY ST. / EL MONTE, CA 91731 Tel: 626-454-8300 Fax: 626-454-8399 www.lalighting.com

