RER120/130/140 Series Installation Instructions




Fixture must be

Fixture Housing


attached to structure ceiling.

NOTE: FIXTURE MUST NEVER BE LIFTED FROM SIDES OR ENDS, LIFT FIXTURES ONLY BY CRADLING IN ARMS, UNTIL THEY ARE SUPPORTED UNIFORMLY BY MOUNTING SYSTEM.

Ceiling Tile



2' ROUND	Ceiling Opening Diameter Flange overall Diameter	X = 21_1/4" Y = 22_3/4"
3' ROUND	Ceiling Opening Diameter Flange overall Diameter	X = 33_1/4" Y = 34_3/4"
4' ROUND	Ceiling Opening Diameter Flange overall Diameter	X = 45-1/4" Y = 46-3/4"











Cut ceiling tile in sections to conceal fixture housing.

<u>Step 3</u>


Connect power source to fixture.

<u>Step 4</u>

Install lamps.

Step 5

After fixture housing is secured, attach flange/diffuser assembly to the fixture housing.





Los Angeles Lighting Mfg. Co.

10141 OLNEY ST. / EL MONTE, CA 91731

Tel: 626-454-8300 Fax: 626-454-8399 www.lalighting.com